

CP-114EL/CP-114EL-I PCI Express Multiport Serial Board Quick Installation Guide

First Edition, July 2008

1. Overview

Moxa's new CP-114EL and CP-114EL-I PCI Express multiport serial boards are designed for POS and ATM applications and for use by industrial automation system manufacturers and system integrators. The boards are compatible with all popular operating systems. Each board also supports data rates of up to 921.6Kbps and provides full modem control signals, ensuring compatibility with a wide range of serial peripherals. In addition, the CP-114EL and CP-114EL-I work with PCI Express $\times 1$, allowing the boards to be installed in any available PCI Express slot (including $\times 1$, $\times 2$, $\times 4$, $\times 8$, $\times 16$, and $\times 32$).

2. Package Checklist

Before installing the PCI Express board, verify that the package contains the following items:

- 1 PCI Express serial board
- · Documentation and Software CD
- Ouick Installation Guide
- · Low Profile Bracket

Notify your sales representative if any of the above items is missing or damaged.

3. Hardware Installation Procedure

The PCI Express board MUST be plugged into the PC before the driver is installed. Follow these steps to install the board in the PC.

STEP 1: Power off the PC.

STEP 2: Plug the board firmly into an open PCI Express slot.

STEP 3: Fasten the holding screw to fix the control board in place.

STEP 4: Connect the connection cable.

STEP 5: Power on the PC; the BIOS will automatically set the IRQ

and I/O address.

4. Software Installation Information

The board MUST be plugged in before installing the driver. See the previous section for instructions on how to install the board in your PC. Refer to the PCI Express Board User's Manual for detailed instructions on installing the drivers for this board.

NOTE: The following procedure shows how to install the CP-114EL driver

Windows 2008/Vista (32-bit/64-bit) Driver Installation

- After powering on your PC, Windows 2008 will automatically detect the PCIe board.
- 2. Insert the PCIe software CD in your CD-ROM drive.
- 3. Select Locate and install driver software (recommended).
- 4. After selecting Search for driver software in this location, select the Include subfolders, and then click Browse. If the system is a 32-bit (x86) platform, navigate to the \CP-114EL Series\Software\Windows 2008_Vista\x86 folder on the CD, if the system is 64-bit (x64) platform, navigate to the \CP-114EL Series\Software\Windows 2008_Vista\x64 folder on the CD, and then click Next to continue.
- Click Install this driver software anyway in response to any warnings that the software has not passed Windows Logo testing.
- 6. After the board has been installed, the installation wizard will guide you through the port installation procedure. Port installation procedure is complete when Port 0 has been set up.
- 7. Use the Device Manager to check the installation of the board and ports. Click the + sign next to Hardware, and then check Multi-port serial adapters and Ports (COM & LPT). Click the +sign next to Multi-port serial adapters, right-click on Moxa CP-114EL Series (PCI Express Bus), select Properties, then choose Port Configuration. Click the port to configure Interface (RS-232, RS-422, 2-wire RS-485, 4-wire RS-485) and Termination Resistor (120Ω, Enable or Disable). If there are warning marks, such as a question mark or exclamation point in front of the board or port icons, examine the Event Log to determine the problem.

Windows 2003/XP (32-bit/64-bit) Driver Installation

- After powering on your PC, Windows 2003/XP will automatically detect the PCIe board.
- 2. Insert the PCIe software CD in your CD-ROM drive.
- 3. Select Install from a list or specific location (Advanced).
- 4. After selecting Search for the best driver in these locations, select the Include this location in the search, and then click Browse. If the system is a 32-bit (x86) platform, navigate to the \CP-114EL Series\Software\Windows XP_2003\x86 folder on the CD, if the system is 64-bit (x64) platform, navigate to the \CP-114EL Series\Software\Windows XP_2003\x64 folder on the CD, and then click Next to continue.
- 5. Click **Continue Anyway** in response to any warnings that the

- software has not passed Windows Logo testing.
- 6. After the board has been installed, the installation wizard will guide you through the port installation procedure, starting with port 0.
- 7. Use the Device Manager to check the installation of the board and ports. Click the + sign next to Hardware, and then check Multi-port serial adapters and Ports (COM & LPT). Click the +sign next to Multi-port serial adapters, right-click on MOXA CP-114EL Series (PCI Express Bus), select Properties, then choose Port Configuration. Click the port to configure Interface (RS-232, RS-422, 2-wire RS-485, 4-wire RS-485) and Termination Resistor (120Ω, Enable or Disable). If there are warning marks, such as a question mark or exclamation point in front of the board or port icons, examine the Event Log to determine the problem.

Windows 2000 Driver Installation

- After powering on your PC, Windows 2000 will automatically detect the PCIe board.
- 2. Insert the PCIe software CD in your CD-ROM drive.
- 3. Select Search for a suitable driver for my device (recommended).
- Under Optional search location, select specify a location. Navigate to the \CP-114EL Series\Software\Windows 2K folder on the software CD.
- Click Continue Anyway in response to any warnings that the software has not passed Windows Logo testing.
- 6. After the board has been installed, the installation wizard will guide you through the port installation procedure, starting with port 0.
- 7. Use the Device Manager to check the installation of the board and ports. Click the + sign next to Hardware, and then check Multi-port serial adapters and Ports (COM & LPT). Click the +sign next to Multi-port serial adapters, right-click on MOXA CP-114EL Series (PCI Express Bus), select Properties, then choose Port Configuration. Click the port to configure Interface (RS-232, RS-422, 2-wire RS-485, 4-wire RS-485) and Termination Resistor (120Ω, Enable or Disable). If there are warning marks, such as a question mark or exclamation point in front of the board or port icons, examine the Event Log to determine the problem.

Linux Driver Installation

 Execute the following commands from the Linux prompt: #mount/dev/cdrom/mnt/cdrom

#cd/

#mkdir moxa

#cd/moxa

#cp /mnt/cdrom/<driver directory>/

driv_linux_smart_vx.x_build_yymmddhh.tgz.

#tar -xzvf driv_linux_smart_vx.x_build_yymmddhh.tgz

2. #cd mxser

#make clean; make install

3. #cd/moxa/mxser/driver #./msmknod 4. #modprobe mxupcie

 Use the Moxa Port Configuration Tool to set Interface and Termination Resistor for the MUE series. The MUE series includes CP-102E, CP-102EL, CP-132EL, CP-132EL-I, CP-114EL and CP-114EL-I.

Usage: muestty <operation> device Device: The MUE series device node

Operation: -h Help

-g Get interface and terminator type
 -i intf
 -t value Set interface type with options below
 -t value Set termination resistor with options below

intf RS232 RS-232 mode RS422 RS-422 mode RS4852W RS-485 2-wire

RS4852W RS-485 2-wire mode RS4854W RS-485 4-wire mode NONTERM Non termination resis

NONTERM Non termination resistor 120TERM 1200hm termination resistor

For example:

value

To set the MUE interface

muestty -i RS422 /dev/ttyMUE2

To set the MUE termination resistor # muestty -t 120TERM /dev/ttyMUE2

6. Use the Moxa diagnostic utility to verify the driver status:

#cd /moxa/mxser/utility/diag #./msdiag

7. Use the Moxa terminal utility to test the tty ports:

#cd /moxa/mxser/utility/term

#./msterm

5. Pin Assignments

The CP-114EL and CP-114EL-I boards come equipped with a female DB44 connector. Cables with different connectors are available to help you connect your device to the board.

Male DB9: Device-side Pin Assignments (CBL-M44M9x4-50)

Male DB9


6 9

Pin	RS-232	RS-422 &	2-wire RS-485
1 111		4-wire RS-485	
1	DCD	TxD-(A)	
2	RxD	TxD+(B)	
3	TxD	RxD+(B)	Data+(B)
4	DTR	RxD-(A)	Data-(A)
5	GND	GND	GND
6	DSR		

7	RTS	
8	CTS	
9		

Male DB25: Device-side Pin Assignments (CBL-M44M25x4-50)

Male DB25



Pin	RS-232	RS-422 &	2-wire RS-485
		4-wire RS-485	
2	TxD	RxD+(B)	Data+(B)
3	RxD	TxD+(B)	
4	RTS		
5	CTS		
6	DSR		
7	GND	GND	GND
8	DCD	TxD-(A)	
20	DTR	RxD-(A)	Data-(A)
22			

6. Specifications

Hardware

Connectors Female DB44
Comm. Controller 16C550C compatible

Interface

Bus Interface PCI Express × 1

Number of Ports 4 Max No. of Boards 4

Signal

RŠ-232 TxD, RxD, RTS, CTS, DTR, DSR, DCD, GND RS-422 TxD+(B), TxD-(A), RxD+(B), RxD-(A), GND RS-485 4-Wire TxD+(B), TxD-(A), RxD+(B), RxD-(A), GND

RS-485 2-Wire Data+(B), Data-(A), GND

Performance

Baudrate 50 bps to 921.6 Kbps

Configuration

Data Bits 5, 6, 7, 8
Stop Bits 1, 1.5, 2
I/O address/IRQ BIOS assigned

Parity None, Even, Odd, Space, Mark

Flow Control RTS/CTS, XON/XOFF

Environment

Operating Temperature 0 to 55°C (32 to 132°F)

Operating Humidity 5 to 95% RH

Storage Temperature -20 to 85°C (-4 to 185°F)

ESD Protection Embedded 15 KV ESD Protection

Optical Isolation 2 KV (only for CP-114EL-I)

Regulatory Approvals EN55022, EN55024, EN61000-3-2,

EN61000-3-3, EN61000-6-2, IEC-61000-4-2, IEC 61000-4-3, IEC 61000-4-4, IEC 61000-4-5,

IEC 61000-4-6, IEC 61000-4-8, IEC 61000-4-11. FCC Part 15 Class B

Warranty 5 years



Click here for online support: www.moxa.com/support

The Americas: +1-714-528-6777 (toll-free: 1-888-669-2872)

Europe: +49-89-3 70 03 99-0 Asia-Pacific: +886-2-8919-1230

China: +86-21-5258-9955 (toll-free: 800-820-5036)

© 2008 Moxa Inc., all rights reserved. Reproduction without permission is prohibited.